

SURE FLAME

SL11E & S1500E CONSTRUCTION HEATERS



November 20, 2020, Rev: 4.31

**SERVICE AND MAINTENANCE MANUAL No. 974-9307
PLEASE RETAIN FOR FUTURE REFERENCE**

SURE FLAME PRODUCTS

A Division of Haul-All Equipment Ltd.
4115 - 18 Ave. N, Lethbridge, Alberta
www.sureflame.ca

SL11E & S1500E CONSTRUCTION HEATERS



GENERAL HAZARD WARNING

Failure to comply with the precautions and instructions provided with this heater, can result in death, serious bodily injury and property loss or damage from hazards of fire, explosion, burn, asphyxiation, carbon monoxide poisoning, and/or electrical shock.

Only persons who can understand and follow the instructions should use or service this heater.

If you need assistance or heater information such as an instruction manual, labels, etc. Contact the manufacturer.



WARNING

Fire, burn, inhalation, and explosion hazard. Keep solid combustibles, such as building materials, paper or cardboard, a safe distance away from the heater as recommended by the instructions. Never use the heater in spaces which do or may contain volatile or airborne combustibles, or products such as gasoline, solvents, paint thinner, dust particles or unknown chemicals.



WARNING

Not for home or recreational vehicle use

READ THIS WARNING FIRST!

The heater is designed and approved for use as a construction heater under CSA 2.14. The primary purpose of construction heaters is to provide temporary heating of buildings under construction, alteration, or repair and to provide temporary emergency heat. Properly used the heater provides safe economical heating. Products of combustion are vented into the area being heated.

The heater is not designed as an Unvented Gas Fired Room Heater under ANSI-Z21.11.2 and should not be used in the home.

ANSI A119.2(NFPA 501C) Recreational Vehicle Standard prohibits the installation or storage of LP-Gas containers even temporarily inside any recreational vehicle. The standard also prohibits the use of Unvented Heaters in such vehicles.

Gas inspection authorities in Canada require that the installation and maintenance of heaters and accessories be accomplished by qualified gas fitters.

Installation must comply with the Natural Gas and Propane Installation Code, CSA B149.1.

We cannot anticipate every use which may be made for our heaters. CHECK WITH YOUR LOCAL FIRE SAFETY AUTHORITY IF YOU HAVE QUESTIONS ABOUT LOCAL REGULATIONS.

Other standards govern the use of fuel gases and heat producing products in specific applications. Your local authority can advise you about these.

FOR YOUR SAFETY

**DO NOT USE THIS HEATER IN A SPACE WHERE
GASOLINE OR OTHER LIQUIDS HAVING
FLAMMABLE VAPOURS ARE STORED OR USED.**

WARNING

Air Quality Hazard

- Do not use this heater for heating human living quarters.
- Use of direct-fired heaters in the construction environment can result in exposure to levels of CO, CO₂, and NO₂ considered to be hazardous to health and potentially life threatening.
- Do not use in unventilated areas.
- Know the signs of CO and CO₂ poisoning.
 - Headaches, stinging eyes
 - Dizziness, disorientation
 - Difficulty breathing, feels of being suffocated
- Proper ventilation air exchange (OSHA 29 CFR 1926.57) to support combustion and maintain acceptable air quality shall be provided in accordance with OSHA 29 CFR Part 1926.154, ANSI A10.10 Safety Requirements for Temporary and Portable Space Heating Devices and Equipment used in the Construction Industry or the Natural Gas and Propane Installation Codes CSA B149.1.
 - Periodically monitor levels of CO, CO₂ and NO₂ existing at the construction site - at the minimum at the start of the shift and after 4 hours
 - Provide ventilation air exchange, either natural or mechanical, as required to maintain acceptable indoor air quality

USA 8-Hr Time weighted average
(OSHA 29 CFR 1926.55 App A)

CO 50 ppm
CO₂ 5000 ppm
NO₂

USA - Ceiling Limit (Short Term
Exposure Limit = 15 minutes)

CO
CO₂

NO₂ 5 ppm

Canada 8-hr time weighted average
WorkSafe BC OHS Guidelines Part 5.1
and Ontario Workplaces Reg 833

25 ppm
5000 ppm
3 ppm (Reg 833)

Canada STEL (15 minutes Reg 833/1
hour WSBC) WorkSafe BC OHS
Guidelines Part 5.1 and Ontario
Workplaces Reg 833

100 ppm
15000 ppm(WSBC)
30000 ppm(Reg 833)
1.0 ppm(WorkSafeBC)
5.0 ppm (Reg 833)

- Ensure that the flow of combustion and ventilation air exchange cannot become obstructed.
- As the building 'tightens up'during the construction phases ventilation may need to be increased.

SPECIFICATIONS

CSA certified to 2.14 Construction Heater

Gases:	Natural or Propane
Capacity: SL11E	1,000,000 Btu/h (290 kW) Maximum
S1500E	1,500,000 Btu/h (440 kW) Maximum
	850,000 Btu/h (2550 kW) Minimum
Orifice Size:	41 DMS (X46)
Blower:	7,000 cfm (12,000m ³ /h)
Electrical Rating:	115 volts, 60 Hz, 9.4 amps, Single Phase
Min. Temperature Rating:	-40 Degrees F/C

Gas Supply: SL11E

	<u>Inlet Pressure</u>		<u>Manifold Pressure</u>
	Max.W.C.(Pa)	Min.W.C.(Pa)	Max.W.C. (Pa)
Propane	14" (3500)	8" (2000)	1.8" (450)
Natural	14" (3500)	8" (2000)	4.8" (1200)

(Minimum inlet pressure is for purpose of input adjustment)

Max. Manifold Pressure Altitude Correction Table

Altitude	Natural Gas	Propane
0' - 2000'	4.8" (1000 Pa)	1.8" (325 Pa)
2500'	4.2" (900 Pa)	1.6" (300 Pa)
3000'	4.2" (875 Pa)	1.6" (300 Pa)
3500'	4" (1050 Pa)	1.6" (275 Pa)
4000'	4" (1025 Pa)	1.6" (275 Pa)
4500'	3.9" (1025 Pa)	1.5" (275 Pa)

Gas Supply: S1500E

	<u>Inlet Pressure</u>		<u>Manifold Pressure</u>	
	Max.WC(Pa)	Min.WC(Pa)	Max.WC(Pa)	Min.WC(Pa)
Propane	14" (3500)	8" (2000)	2.7" (450)	0.75" (190)
Natural	14" (3500)	8" (2000)	7.2" (1200)	2.0" (500)

Max. Manifold Pressure Altitude Correction Table

Altitude	Natural Gas	Propane
0' - 2000'	7.2" (1800 Pa)	2.7" (675 Pa)
2500'	6.5" (1625 Pa)	2.4" (600 Pa)
3000'	6.5" (1625 Pa)	2.4" (600 Pa)
3500'	6.3" (1575 Pa)	2.4" (600 Pa)
4000'	6.2" (1550 Pa)	2.3" (575 Pa)
4500'	6.1" (1525 Pa)	2.2" (550 Pa)

INSTALLATION

The Sure Flame Models SL11E & S1500E are direct fired gas heaters intended to be used primarily for the temporary heating of buildings under construction, alteration, or repair. Since all the products of combustion are released into the area being heated, it is imperative that adequate ventilation is provided. The flow of supply air and combustion gases must not be obstructed in any way. Do not use the heater with ductwork as this will restrict the flow of supply air.

1. Install the heater in a horizontal position at least 10 feet (3 M) from any LP-gas container, and allow the following clearances from any combustible materials:

Front Outlet: 20 feet (6 M) Sides: 2 feet (0.6 M)

Intake: 2 feet (0.6 M) Top: 4 feet (1.2 M)

Front Outlet must not be directed at any LP-gas container within 20 feet (6 M).

Make sure that no flammable vapours are present in the space where the heater is being used.

The installation of this heater **MUST** be in accordance with the appropriate following Standard:

Natural Gas and Propane Installation Code, CSA B149.1.

2. When connecting the heater to a natural gas or propane supply line ensure that the pressure at the heater inlet is within the specified range. Please refer to Propane and Natural Gas Installation sections on page 7. Excessive pressure (over 1/2" psi) will damage the controls and void the warranty.
3. Visually inspect the hose assembly and ensure that it is protected from traffic, building materials, and contact with hot surfaces. If it is evident that there is excessive abrasion or wear, or the hose is cut, it must be replaced.
4. After installation, check the hose assembly for gas leaks by applying a water and soap solution to each connection.
5. Connect the heater to an adequate 115 volt electrical supply as specified on the rating plate. For protection against shock hazard the supply cord must be plugged directly into a properly grounded three-prong receptacle. The electrical installation of the heater **MUST** be in accordance with CSA Standard C22.1 Safety Standard for Electrical Installations.
6. In all applications, install the heater in such a manner that it is not directly exposed to water spray, rain and/or dripping water.

**THE INSTALLATION AND MAINTENANCE OF
THE HEATER MUST BE ACCOMPLISHED BY
A QUALIFIED SERVICE PERSON.**

INSTALLATION USING A PROPANE SUPPLY TANK

1. When installing the heater for use with propane gas, set the gas selector valve to “Propane” and lock in position.
2. The supply container must be equipped with a UL listed Gas Pressure Regulator. This is essential to reduce the gas pressure to a safe transmittable pressure. This pressure must further be reduced so the gas pressure does not exceed the maximum input pressure of the heater. This can be accomplished by placing a suitably sized second stage gas regulator on the valve train at the heater. This regulator should also be a UL listed LP Gas Pressure Regulator.
3. Arrange the propane supply system to provide for vapour withdrawal from the operating container. Supplying liquid propane to the heater is dangerous and will damage the components.
4. Ensure that for the surrounding temperature the size and capacity of the propane supply container is adequate to provide the rated Btu/h input to the heater.
5. Turn off the propane supply valve at the container when the heater is not in use.
6. The installation must conform with local codes, or in the absence of local codes, with the Natural Gas and Propane Installation Code, CSA B149.1.
7. When the heater is to be stored indoors the propane container must be disconnected from the heater and the container moved away and stored in accordance with the above National Standard.

INSTALLATION FOR NATURAL GAS APPLICATIONS

1. When installing the heater for use with natural gas, set the gas selector valve to the “Natural” position.
2. A regulator must be installed on the heater to ensure that the pressure to the heater does not exceed 1/2 psi inlet pressure.
3. The installation of this heater to a natural gas supply must conform with all applicable local codes or, in the absence of local codes, with the Natural Gas and Propane Installation Code, CSA B149.1.

OPERATING INSTRUCTIONS


1. Set GAS SELECTOR VALVE to gas being used. The conversion shall be done by the owner or lessor of the equipment.

NOTE: When using Propane Gas the Selector Valve **MUST** be locked in position.

NATURAL GAS



PROPANE



2. Ensure the FIRING VALVE is in the “ON” position.
3. Connect power cord to a 115 volt supply.
4. Open gas supply.
5. If equipped with a thermostat, set the thermostat to the desired temperature.
6. Push START button. After a short delay, the heater will start.

NOTE: The SL11E, if equipped with a thermostat, will cycle between on and off as required.

NOTE: The S1500E will cycle between high flame, low flame, and off as required.

7. To stop: push STOP button. If the heater is to remain off, disconnect power cord and close gas supply.

The appliance area should be kept clear and free from combustible materials, gasoline, and other flammable vapours and liquids.

Ensure that the flow of supply air and combustion gases is not obstructed.

The installation and operation of the heater shall comply with the code requirements specified by the authorities having jurisdiction. In the absence of specific Local Codes the installation of this Construction Heater **MUST** conform with the following National Standards:

Safety Standard for Electrical Installations, CSA C22.1

(Canadian Electrical Code Part 1)

Natural Gas and Propane Installation Code, CSA B149.1

General criteria for the use of construction heaters may be found in the applicable sections of either the following Standard:

Natural Gas and Propane Installation Code, CSA B149.1.

COMMON INSTALLATION AND OPERATIONAL PROBLEMS

1. LOW VOLTAGE

This is one of the most common problems and is usually the result of the supply cord having too small a wire gauge for its length. Low voltage results in the motor overheating, burnt relay contacts, or a relay that will not maintain contact.

2. SUPPLY LINE TOO SMALL

3. INSUFFICIENT VAPORIZATION AT SUPPLY

Normally caused by too small size of supply tank.

4. IMPROPER GAS SUPPLY PRESSURE

Usually a result of supply pressure being too high because of improper or lack of regulation.

5. DIRTY GAS SUPPLY

Dirty gas can cause strainers to plug or form a build-up in the burner orifice.

6. LACK OF PREVENTATIVE MAINTENANCE

Heaters must be cleaned as required, especially when used in a dirty environment.

7. IMPROPER SUPPLY OF FRESH AIR

It is normally recommended that the intake air of the heater be taken from outside the enclosed area. This provides a slight pressurization and prevents any problems associated with recirculation.

ON-SITE SAFETY PROBLEMS

1 BYPASSING OF DEFECTIVE COMPONENTS

This is a potentially dangerous problem which saves short term expense at the risk of a large future cost. Any heaters found in this condition should be removed from service immediately.

2 IMPROPER ENCLOSURES

When heaters are installed partially to the outside for fresh air intake, strict adherence must be made to the minimum clearance to combustibles given on the instruction plate. Wood framing around a heater is a hazard and should not be used.

3 SUPPLYING LIQUID PROPANE TO HEATER

This heater is not intended to burn liquid propane. To minimize the damage, shut off the gas supply and let the heater run until all of the liquid in the lines has been burnt.

PREVENTIVE MAINTENANCE

Sure Flame Construction Heaters are built to withstand the rigours of operating on construction sites, mining applications, and a multitude of other locations where heaters are used. To maintain reliable performance it is necessary to perform regular maintenance.

Heater should be inspected before each use, and at least annually by a qualified service person.

A. VISUAL CHECKS

The following items should be checked for excessive wear or damage:

- 1) Wheels
- 2) Cords and Connectors
- 3) Wiring and Conduit
- 4) Heater Shell (including heat shield) and Control Box
- 5) Valve Train

It is recommended that units purchased as spares be rotated periodically, so that each unit will be placed in operation at least once every 90 days.

B. BURNER

Flame Rod and Insulator - Clean with soap and water or solvent on a routine basis. Any build up on burner should also be removed at this time.

Ground Wire - Ensure that the ground wire is secured to the burner. This is necessary for the flame detection system to operate.

Spark Plug - Clean with solvent and check spark gap. Gap should be set to 1/8".

C. CONTROL BOX

The inside of the control box should be cleaned using a dry cloth or by blowing compressed air. Do not use any liquid or aerosol spray cleaners. Also check that all electrical connections are snug and tight.

D. MOTOR

The electric motor on the SL11E & S1500E Heaters is fitted with sealed bearings and no oiling is required. Keep the motor clean by blowing or wiping off dust or dirt in order to prevent it from over heating.

E. FAN

Check for dust or dirt build up on fan blades. Check the tightness of the set screw and run the heater to check for fan vibration.

TROUBLE SHOOTING

The troubleshooting section has been divided in to six tables. Choose the appropriate table from the list below:

Chart A – Heater does not start, fan does not start

Chart B – Heater does not start, fan starts, no spark, no flame

Chart C – Heater does not start, fan starts, spark, no flame

Chart D – Heater starts, flame lights but goes out after a few seconds

Chart E – Heater starts, but fails during operation

Chart F – Other problems

Chart A – Heater does not start, fan does not start

Symptom	Possible Causes	Indicators Outside Control Box					Indicators Inside Control Box						
		Green Start Switch	Red Stop Switch	Thermostat Power	Thermostat Stage 1 Light †	Thermostat Stage 2 Light †	L2	L6	L7	L8	L12	Flame Control LED	
Green start light does not come on when start switch is pressed.	No electrical supply	off	off	off	off	off	off	off	off	off	off	off	
	Stop switch fails open	off	off	off	off	off	on	off	off	off	off	off	
	Start switch fails open	on/ off	off	off	off	off	on	off	off	off	off	off	
Green start light comes on when pressed, but goes off when released. L12 is off	Logic relay failure	on/ off	off	off	off	off	on	off	off	off	off	off	
Green start light comes on when pressed, but goes off when released. L12 flashes when start switch released.	Fuse failure	on/ off	off	off	off	off	on	off	off	off	*	Off	
Green start light is on, but red stop light remains off during attempts to start.	Reset switch fails open	on	off	off	off	off	on	off	off	off	off	Off	
	Thermostat stage 1 fails open †	on	off	-	-	-	on	off	off	off	off	off	
	Flame control failure – Power in	on	off	on	-	-	on	off	off	off	off	off	
	Flame control failure – Thermostat in †	on	off	on	on	-	on	off	off	off	off	off	
	Flame control failure – Motor out	on	on	on	on	-	on	off	off	off	off	*	
Green start light is on, red stop light comes on during attempts to start	Motor relay fails open	on	on	on	on	-	on	on	off	off	off	*	
	Motor failure	on	on	on	on	-	on	on	off	off	off	*	
	Low Voltage (long extension cord or too many items on circuit). Motor relay may chatter.	on	on	on	on	-	on	*	*	off	off	off	
	Air switch fails closed	on	on	on	-	-	on	off	off	off	off	*	

† Thermostat is optional on model SL11E

Chart B – Heater does not start, fan starts, no spark, no flameSymptom	Possible Causes	Indicators Outside Control Box						Indicators Inside Control Box				
		Green Start Switch	Red Stop Switch	Thermostat Power	Thermostat Stage 1 Light †	Thermostat Stage 2 Light †	L2	L6	L7	L8	L12	Flame Control LED
Air blowing through heater in reverse. No gas odor at heater outlet. L7 light is off. Voltage between N2 and L15 is 120V during attempt to start.	Motor wired incorrectly	on	on	on	on	-	on	on	off	off	off	*
	Air tubes set in wrong position	on	on	on	on	-	on	on	off	off	off	*
	Air switch fails open											
	Air switch set to too high a pressure											
	Air tubes plugged											
No gas odor at heater outlet. L7 light is off. Voltage between N2 and L15 is 0V during attempt to start.	Strainer plugged or dirty	on	on	on	on	-	on	on	off			*
	Too small of a hose, too long of a hose, blocked hose											
	Too low of inlet pressure											
	Second stage regulator set too low											
	Propane tank too small to vapourize fast enough, tank freezes											
No gas odor at heater outlet. L7 light is on.	Upstream regulators installed backwards											
	Flame control failure – Air in	on	on	on	on	-	on	on	on	off		*
	Flame control failure – spark out											
	Spark plug fails	on	on	on	on	-	on	on	on	on/	off	***
	Flame rod and spark plug wires reversed											
Gas odor at heater outlet. L7 light on. L8 light on, then off.	Spark plug wire damaged											

† Thermostat is optional on model SL11E

Chart C – Heater does not start, fan starts, spark, no flame

Possible Causes		Indicators Outside Control Box					Indicators Inside Control Box					
Symptom		Green Start Switch	Red Stop Switch	Thermostat Power	Thermostat Stage 1 Light †	Thermostat Stage 2 Light †	L2	L6	L7	L8	L12	Flame Control LED
No gas odor at heater outlet. L8 light is off. Voltage between N2 and L17 is 120V during attempt to start.	Limit switch fails open	on	on	on	on	-	on	on	on	off	off	***
No gas odor at heater outlet. L8 light is off. Voltage between V1 and V2 on flame controller is 0V during attempt to start.	Flame control failure	on	on	on	on	-	on	on	on	off	off	***
No gas odor at heater outlet. L8 light is on, then off.	Manual valve closed	on	on	on	on	-	on	on	on	on/ off	off	***
	Solenoid valve fails closed											
	Too high of inlet pressure. Second stage regulator set too high. (This may cause the 2-stage regulator to be damaged)											
	2-stage regulator installed backwards	on	on	on	on	-	on	on	on	on/ off	off	***
Gas odor at heater outlet. L8 light on, then off.	Burner orifices plugged or dirty											
	Spark plug gap too large (weak spark) or too small. Gap should be set to 1/8 inch.											
	Low flame regulator setting too low											

† Thermostat is optional on model SL11E

Chart D – Heater starts, flame lights but goes out after a few seconds

Symptom	Possible Causes	Indicators Outside Control Box						Indicators Inside Control Box					
		Green Start Switch	Red Stop Switch	Thermostat Power	Thermostat Stage	Thermostat Stage	Thermostat Stage	L2	L6	L7	L8	L12	Flame Control LED
Connect DC current meter with microampere range to terminals FC+ and FC- of the flame controller. Start heater. Check reading once flame is established. Reading is 1.0 microamperes or higher	Flame control failure – Flame sensing	on	on	on	on	Thermostat Stage	Thermostat Stage	on	on	on	on/off	off	***
	Flame rod dirty, cracked, or otherwise defective.	on	on	on	on	on	on	on	on	on	on/off	off	***
	Flame rod wire loose or damaged	on	on	on	on	on	on	on	on	on	on/off	off	***
	Burner not grounded	on	on	on	on	on	on	on	on	on	on/off	off	***

† Thermostat is optional on model SL11E

Chart E – Heater starts, but fails during operation


Symptom	Possible Causes	Indicators Outside Control Box					Indicators Inside Control Box					
		Green Start Switch	Red Stop Switch	Thermostat Power	Thermostat Stage 1 Light	Thermostat Stage 2 Light	L2	L6	L7	L8	L12	Flame Control LED
Normal flame length prior to failure. Three flashes on flame control LED.	Low Voltage (long extension cord or too many items on circuit)	on	on/ off	on	on	-	on	on/ off	on/ off	off	off	***
Smaller than normal flame prior to failure. Single flash on flame control LED.	Propane tank too small to vapourize fast enough, tank freezes Strainer plugged or dirty	on	on	on	on	-	on	on	off	off	off	*
Normal flame length prior to failure. Three flashes on flame control LED. Immediately after failure, voltage between N2 and L17 is 120V, between N2 and L16 is 0V.	Limit switch failure – too sensitive	on	on	on	on	on	on	on/ off	on/ off	off	off	***
Longer than normal flame before failure, possibly shooting outside of heater body. Three flashes on flame control LED. Immediately after failure, voltage between N2 and L17 is 120V, between N2 and L16 is 0V.	Changeover valve set to natural gas when connected to propane. Connected to liquid propane Too high of inlet pressure Second stage regulator set too high High flame regulator setting too high	on	on	on	on	on	on	on/ off	on/ off	off	off	***

Chart F – Other Problems

Symptom	Possible Causes	Indicators Outside Control Box						Indicators Inside Control Box					
		Green Start Switch	Red Stop Switch	Thermostat Power	Thermostat Stage 1 Light †	Thermostat Stage 2 Light †		L2	L6	L7	L8	L12	Flame Control LED
Excessive vibration or noisy operation.	Damaged or unbalanced fan blade	on	off	on	on	-		on	on	on	on	off	off
Fan motor starts immediately when heater is plugged in, even if thermostat is not calling for heat	Motor relay fails closed	off	off	off	off	off		on	off	off	off	off	off
Heater will start as soon as it is plugged in. Stop button will reset the heater.	Start switch fails closed	on	off	on	-	-		on	-	-	-	-	-
Flame length shorter than normal	Low flame regulator setting too low	on	off	on	on	-		on	on	on	on	off	off
Normal operation except flame length shorter than normal	High flame regulator setting too low	on	off	on	on	on		on	on	on	on	off	off
Small flame, otherwise functions normally.	Changeover valve set to propane when connected to natural gas	on	off	on	on	-		on	on	on	on	off	off
Heater will never go to high flame.	Thermostat stage 2 fails open	on	off	on	-	-		on	on	on	on	off	off
Normal operation, but low flame longer than normal.	Low flame regulator setting too high	on	off	on	on	-		on	on	on	on	off	off
Gas will flow to burner immediately when supply to heater is opened	Solenoid valve fails open	-	-	-	-	-		-	-	-	-	-	-
Gas will flow to burner immediately when supply to heater is opened	Solenoid valve leaks	-	-	-	-	-		-	-	-	-	-	-


† Thermostat is optional on model SL11E

Replacement Parts




Ref	Part No.	Description	Ref	Part No.	Description
A1	S1505-56	Heater Body	C12	S1500-109	Air Tube
A2	2446	Limit Switch, 180 ° F	C13	5515	Rubber Grommet
A3	S1500-104	Control Box Lid	C14	2554	Compression Fitting, 1/4" Tubex 1/8" MNPT
A4	S1500-501	Control Box	C15	S1500-502	Air Tube Bracket
A5	7723	Control Box Seal	C16	9348	Brass Elbow
A6	2423	Fan Blade, 24"	C17	S1500-714	2-Stage Thermostat w/ Cable (S1500E Only)
A7	9262	Motor, 1HP	D1	9826	Relay Holder Clip
A8	SL11B-53	Screen	D2	9264	Relay
A9	6119	Wheel	D3	S1500-105	DIN Mounting Rail
B1	BV85-50	Burner	D4	4655	End Plate for 4668
B2	2143	Spark Plug	D5	4668	Ground Terminal Block (green)
B3	SL11B-86	Flame Rod	D6	4654	End Plate for 4528
B4	2539	Manual Shut-Off Valve, 1-1/2"	D7	4658	Terminal Block 2P + 2P (gray)
B5	S1505-81	Gas Selector Valve, 1-1/2"	D8	4657	End Plate for 4669
B6	2537	Solenoid Valve, 1-1/2"	D9	4669	Terminal Block 4P (gray)
B7	4490	2-Stage Regulator, 1-1/4" (S1500E Only)	D10	4527	Fused Terminal Block (gray)
B8	2526	1-1/2" Appliance Regulator (SL11E Only)	D11	4529	Terminal Block 3P (gray)
B9	S1500-86	Strainer Assembly, 1-1/4" (S1500E Only)	D12	4524	End Plate for 4529
B10	SL11B-715	Strainer Assembly, 1-1/2" (SL11E Only)	D13	4530	Terminal Block 2P (gray)
B11	2528	Regulator (Optional)	D14	4525	End Plate for 4530
C1	9624	Flame Controller	D15	8659	Utility Box
C2	9612	Start Button Assembly	D16	9271	Fuse Holder
C3	S1500-718	Start Contact Block Assembly	D17	9270	Fuse 2A
C4	9611	Stop Button Assembly	D18	4622	End Plate for 4527
C5	S1500-717	Stop Contact Block Assembly	D19	4523	Jumper 5 Pole
C6	S1500-713	Thermostat Jumper Assembly (S1500E Only)	D20	4528	Jumper 2 Pole
C7	8682	Thermostat Receptacle (S1500E Only)	D21	4652	Terminal Block w/ Light 2P + 2P (red)
C8	3868	Power Cord, 24"	D22	9443	Jumper 3 Pole
C9	5509	Snap Bushing, 1/2"	D23	WR41EX-60	Ground Terminal Block (green/yellow)
C10	S1500-710	Adjusted Air Switch	D24	WR7BFY-66	Ignition Wire
C11	1707	Silicone Tubing			Flame Rod Wire


SL11E Connection Wiring Diagram



SL11E Ladder Wiring Diagram




S1500E Connection Wiring Diagram




Note: All wires 18 Ga STR T&W 600V unless otherwise specified.

Downloaded From: <http://www.jstor.org> on Tue, 24 Jun 2014 12:02:42 PM
All use subject to [JSTOR Terms and Conditions](#)

S1500E Ladder Wiring Diagram



Two-Stage Thermostat Wiring Diagram (S1500-714)



LPG - PROPANE FUEL

VAPORIZATION RATE

The following chart shows the amount of BTU's that various sizes of tanks will produce on the average at specific temperatures and regular atmospheric conditions.

Tank Size Gallons (Pounds)	Maximum intermittent withdrawal rate (BTU/hr) without tank frosting* if lowest outdoor temperature (average for 24 hours) reaches.							
	+40 F.	+30 F.	+20 F.	+10 F.	0 F.	-10 F.	-20 F.	-30 F.
150 (600)	214,900	187,900	161,800	148,000	134,700	132,400	108,800	107,100
250 (1000)	288,100	251,800	216,800	198,400	180,600	177,400	145,800	143,500
500 (2000)	478,800	418,600	360,400	329,700	300,100	294,800	242,300	238,600
1000 (4000)	852,800	745,600	641,900	587,200	534,500	525,400	431,600	425,000

* Frosting on the outside of the tank acts as an insulator, reducing the vaporization rate.

MAXIMUM BTU CONTENT (PROPANE)

The following table shows the maximum BTU's that a cylinder contains.

CYLINDER SIZE	BTU CONTENT
100 pound	2,159,100
250 gallon USA	22,922,500
500 gallon USA	45,845,000
1000 gallon USA	91,690,000

CAUTION: In extremely cold weather it is impossible to completely empty a propane cylinder.

PRESSURE & FLOW EQUIVALENTS

1 Std. Atmosphere =	14.73 lb./sq. in. =	1.014 bar
1" Water Column (W.C.) =	0.58 oz./sq. in. =	2.49 millibar
11" Water Column =	0.4 lb./sq. in. =	27.39 millibar
1 lb./sq. in. (psig) =	27.71" W.C. =	0.0689 bar
1" Mercury =	0.49 psig =	33.86 millibar
1 Std. Cubic Ft./Hr. =	2,500 BTU/Hr. =	0.02832 cu. m/hr.
1 BTU/Hr. =	0.2931 Watts	